



Contents

Dear customer —	3
Precautions before Use ————	- 3
Product characteristics	- 3
Safety precautions	4
Regarding Power Supply	- 4
000.90	- 4
Cleaning ————	
Others ————	- 5
Installation	- 6
Description of Product	6
Direction to use	7
Screen	- 7
DRAIN WATER Ready screen	- 7
Direction - Operation screen	- 8
Error screen	– 8
Change the electrolyte container ——	9
Precautions for use	9
Non-acidic hypochlorous ————acid wate Characteristi	- 10
Confirmation before requesting A/S -	- 10
Product Warranty	- 11

Dear customer

Thank you for purchasing our products.

Please read this manual carefully to ensure proper use of the product,

- If you have any inquiries during use, or in the event that this product doesn't function properly, refer to this manual.
- We assume no responsibilities for any accidents arising out of improper use of this
 product as specified in the manual
- Keep the manual as well as the warranty in a safe place so it will be handy when you need it the next time



Precautions before Use





Never use the water that comes out of the product for drinking as it is sterilizing water, not drinking water with non-acidic hypochlorous acid





Since the electrolyte contains a small amount of hydrochloric acid, corrosion can easily occur when the electrolyte comes in contact with metal, Care with handling, and wash with running water when contaminated with electrolyte.





In case of contact with the human body while handling the electrolyte, wash it with running water





A small amount of chlorine gas is generated during the production of electrolytic sterilization water, so please install it in a well-ventilated place

Product characteristics

CPU built-in, fully automated system,

All operations of the product are controlled by a semiconductor CPU that automatically finds optimal operating conditions using the flow rate and the measured current value,

Automatic water outlet control

Pressing the touch button can release water or stop the flow of water.

Voice announcement,

Various functions and safety warning voice guidance make it safe and convenient to use.

Indication and notification of electrolyte replacement

This product informs you that you can replace it through alarm and voice guidance when the electrolyte is all used up,

3

AutoZen 7 Safety precautions

Safety precautions are provided for the safe and proper use of this product and prevent unexpected danger or possible damage. Make sure you will be familiar with the safety precautions for the proper use of the product,

The "DANGER" sign indicates an imminent hazard that, if not avoided, will result in serious injury or death,



The "WARNING" sign indicates a potential hazard that, if not avoided, will result in significant injury to the body or damage to property.

The "ATTENTION" sign indicates a potential hazard that, if not avoided, will result in minor injury to the body or damage to properly,

Regarding Power Supply



Do not use a damaged power cord or loose connector otherwise, electric shock or fire may occur.





Do not pull the power cord or never touch it with wet hands. otherwise, electric shock or fire may occur.



Do not forcibly bend the power cord and make sure the power



cord isn't squeezed, damaged or deformed by heavy things. Otherwise, electric shock or fire may occur,



In the event that water gets into the power supply unit, pull the power cord and make it completely dry prior to use. Otherwise electric shock or fire may occur.



During product repair/inspection and/or parts replacement, be sure to unplug the power cord. Otherwise, electric shock or fire

Otherwise, electric shock or fire may occur.



Use a dedicated connector per outlet for each electrical product.

Do not allow the power cord to be connected or processed at your discretion, Otherwise, electric shock or fire may occur



Do not allow the power cord to be plugged in and unplugged repeatly. Otherwise, electric shock or fire may occur,



In the case of a damaged power cord, do not replace it with another one at your discretion, Contact our service center to g a new power cord, Otherwise, electric shock or fire may occur



Usage



In the case where raw water isn't used over a long period, lock the raw water valve and pull the power cord out, Otherwise, electric shock, fire or leaks may occur.



Never poke or scratch the touch screen with a sharp thing, otherwise, may cause electric shock or damage to the product, (Give a light touch to the touch screen.)



ventilated place and use it

Cleaning



If electrolyzed water is not used for a long period of time, close the water inlet valve and unplug the power cord. Otherwise, electric shock, fire or leakage may occur



AutoZen 7

During the humid summer months condensed water can flow out of the product, which is normal for the product, However, in case condensed water keeps flowing out of the product even in the cold weather, contact our service center, Leaks may occur,,

The chlorine gas that is not dissolved in the water discharged during the electrolyte discharge is mixed, so install it in a well-



Dry thoroughly dust or water on the area where the power cord and pin are come into contact



Do not place a vessel filled with water, pharmaceuticals, food, and small metals on this product, if introduced into the product, may cause electric shock or fire,



Do not spray water onto the main body or do not clean the main body with damped cloth, Otherwise, a short circuit or electric shock may occur. In the case where the LCD gets contaminated, clean it with a wet cloth.)





In the event that abnormal noise, or burning smell or smoke is generated from the product, immediately unplug the power connector and contact our service center. Otherwise, fire may occur

In the event that water flows from inside of the product, or water

present around the product, lock the raw water valve, pull out the

To ensure electrolytic sterilization water, the electrolytic tank is

replaced when electrolysis performance is issued by an error,

Product performance and sterilization may deteriorate if an electrolytic tank at the end of its life cycle is being used.

power cord, and contact over service center,





When moving this product to another place, don't drag the powe cord, which may cause electric shock or fire





Do not disassemble or refurbish this product at your discretion Otherwise, electric shock or damage to the product may occur,





Do not use in tanks with goldfish, tropical fish, etc. Environment change may cause death



Safety precautions

AutoZen 7

Description of Product

AutoZen 7

Direction to use You shou

You should be familiar with how to operate it after installation,

AutoZen 7

Installation



Do not install this product near heat appliances, Never place a candlelight or cigarette on this product, Otherwise, fire may occur,



Do not install this product at a slopped location and do not apply excessive force or impact to this product, which may cause physical injuries and damage to the product,



Do not connect raw water to the hot water supply line.


Otherwise, a failure or accident may occur. (Be sure to connect raw water to the cold water supply line.)



/ Install and use the product near the sink







- 1. Lock the main valve on the water pipe
- 2. Separate the tap from the water pipe.
- 3. Turn the adapter to allow it to be fitted in the water pipe.
- 4. Assemble the tap back into the adapter.
- 5. Connect the valve to the adapter before connecting the water inlet hose to the nipple,

Bottom

Front



Back



Keyhole Slot

With the screw provided Fix it on the wall at the intervals below.

Electrolyte container replacement cover.


provided Fix it on water inlutervals below.

Power Switch



- 1 전해수기 출수 동작 버튼
- 2 설정 버튼
- ③ 화면을 3초간 누르면 자동/수동 으로 전환된다.

자동설정



수동설정

동작/정지 스위치로 사용 가능

DRAIN WATER Ready screen



- If you press the operation button in the center, it outputs the voice "Electrolyzed water is dispended" and starts electrolysis
- It is a window to check the status of the electrolyte and internal operation required for hypochlorous acid water (HOCL) generation, Dispending proceeds when the preparation is complete,

Direction - Operation screen



Flow rate

Displays the current flow rate,

Electrolyte Usage

Displays the amount of electrolyte used, If it exceeds 1,000mL, it is counted again from 0 and displayed as mL 1 after the unit, The number after mL is automatically increased by 1,000 units and displayed,

HOCL Total Production

Displays the total amount of HOCL produced, If it exceeds 10,000L, it counts again from 0 and is displayed as L 1 in the unit, The number after L automatically increased by 10,000 units and displayed.

Operating time

Displays the total usage time of the device, If it exceeds 1,000h, it counts again from 0 and is displayed as run time 1. The number after the run time automatically increased by 1,000 units and displayed.

Stop operation

When the stop button is pressed, the voice "Stop water dispense" is output and the operation standby screen is displayed,

An alarm sounds every 10 seconds during operation,

6 - - - - - - -

Direction to use AutoZen 7

Settings screen - Settings



Volume setting :

You can adjust the volume level in $0{\sim}15$ steps with "+" and "_" . 0-15 steps

Language setting:

You can select the language with "+", "_"

Continuous water dispensing volume setting:

Set the continuous water dispensing volume from 5 to 200L with "+", "_". An alarm is displayed and forcibly stopped if the continuous water discharge exceeds the set

Setting screen - time setting



Time setting: Set year/month/day/hour/minute using "+" and "_".

Error screen



If the water intake is less than 0.5L or the value greater than 3L continues for 30 seconds after water dispensing, the water intake is stopped and an error screen is output with an error voice. Click the OK button to clear the error

Error screen 2



Occurs when the current flowing through the electrolyzer does not exceed a certain value after 30 seconds of water discharge operation, It occurs when the electrolysis performance deteriorates due to deterioration of the electrolyzer's warranty life of 3000 hours or more. For the above error, contact the A/S center to replace the electrolyzer.

Error screen 3



f the resistance of the electrolyzer does not reach a certain value after 30 seconds of water outflow, it is judged that the electrolyte is not supplied. The error is cleared by replacing the electrolyte container that contains the electrolyte.

Error screen 5



If the set continuous water dispensing amount during water dispensing operation, an error sound and an error window are displayed, and water dispensing is stopped. If you press the OK button, the error screen disappears and it moves to the operation standby screen.

Error screen 6



It occurs when there is no communication between the main board and the control board continuously for 5 seconds. The above error should be checked by contacting the A/S center.

Error screen 7



Occurs when data to be stored in memory such as set values is not saved. The above error should be checked by contacting the A/S center

Change the electrolyte container. AutoZen 7



When the electrolyte is exhausted, the replacement of the electrolyte is notified by voice

- 1. Remove the electrolyte container cover from the device.
- Turn the electrolyte container to the left and separate it from the device, (If the electrolyte leaks, wipe it off with a wet tissue immediately.)
- 3. Press and insert a new electrolyte container, turn it to the right to install it,
- 4. Mount the electrolyte container cover,

Precautions for use

AutoZen 7

- 1, Never Modify the unit as your will
- 2, Never use of store this unit in a place with temperature or damp,
- 3. Use this unit first checking the rated voltage
- 4. "This device is not designed for use by people (including children) who lack physical, sensory, and mental abilities or lack of experience and knowledge who cannot use the device safety without supervision or instructions,"
- 5. It is recommended to monitor children so that they do not play with devices.
- Never use a place or water as described below
- place water is easy to be frozen
- place where you can come into direct contact with the fire.
- closed space.
- Water above 40°C.
- Not suitable for substances other than water.
- In the case of storing and using the discharged electrolytic sterilized water
- Make sure to mark electrolytic sterilization water and store it in a plastic container in an airtight state, If it comes into contact with air, sterilization may be lost,
- Do not store electrolytic sterilized water using a metal container,
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similar qualified persons in order to avoid a hazard
- When the water supply is cut off the power plug must be plugged out

Non-acidic hypochlorous acid wate Characteristic

AutoZen 7

Confirmation before requesting A/S AutoZen 7

ltem		Specifications
M	lodel Name	AUTOZEN7
Bateo	d Power Supply	220-240V~ / 50-60Hz
Water	Supply Method	Direct type
Body	Dimension	340*340*150(H*W*D)mm
	Weight	Approx, 5kg
Allowab	ole water pressure	100 ∼ 500 kPa
Allowa	able Temperature	5~40℃
Electrolysis Device	Electrolyisis	Continuous Electrolysis
	Generating Capacity	1.0~2.5 L/min
	Electrode	Iridium/titanium
	рН	5~6.5
Electrolytic Sterilization Water	Chlorine Concentration(ppm)	10~50
	Amount Generated (L/min)	1.0~2.5 L/min
	Electrolyzed water	6% HCL

Symtoms	Check Points	Measures to be taken	
	Check that the valve on the raw water supply line is closed.	Open the valve	
no water leakage or when the amount of electrolytic sterilization water is different from the standard	Check hoses for bends or folds,	Extend hose.	
	Check for low flow (less than 1 º /min).	Please contact the A/S center to install the water pump	
	Check that the water supply is shut off and the water line is frozen.	Wait for water to come out of the water supply pipe.	
When the amount of	Check the date of manufacture of the electrolyte is at least one year.	Replace with new electrolyte	
residual chlorine is smal	Make sure the flow is higher.	Reduce the amount of water you get,	
Electrolyte leaks	Check that the electrolyte is installed correctly	Immediately unplug the power cord and request after-sales service,	
from the product	Excluding the electrolyte, check the inside of the product for leaks,		

Product Warranty

AutoZen 7



Product Warranty (HOCl manufacturing machine)



- 1.If the product of our company is damaged during normal use according to the user manual within the warranty period, we will repair it free of charge. (If it is difficult to confirm the purchase date of the product, the warranty period will be added from the date of manufacture or 3 months from the date of import clearance.)
- We charge for repairing if it occurs after the warranty period has elaosed.
- If household products are used for business purposes (sales activity, abnormal usage environment, etc.) or industrial products, the nonproductive warranty period is ½ (6 months).
- 4. In case of malfunction, present the product warranty to the place of purchase or A/S center and receive service.

Manufacturer: Iwin (www.iwin2.co.kr) E-mail: ideawin2@naver.com
Address: #321, Jikji Smart Tower, 76, Jikjidaero 436beon-gil,
Heungdeok-gu, Cheongju-si, Chungcheongbuk-do

A/S and product inquiry: $070 \cdot 4797 \cdot 3679$

product	model
Date of purchase	
Customer name	Contact
Address	
Agency	Contact
Address	_







Type of Consumer Damage		Compensation Details	
		Within the warranty period	After the warranty period
In case of performance or functional failure that occurs naturally under normal use (within the warranty period)	When major repairs are required within 10 days of purchase	Product exchange or purchase price refund	
	when repair is required for important parts within 1 month of purchase	Product replacement or free repair	
	When the replaced product requires major repair within one month	purchase price refund	
	When exchange is not possible	puici ase price reiuriu	Paid repair
	In case of a defect	free repair	
	Repaired 3 times for the same defect, but the failure recurred (4th time	Product exchange or purchase price refund	
	Repaired a total of 4 times due to failures in various parts, but the failure recurred (5th time)		
	When repair is not possible		Refund by
	When the business operator loses the product requested by the consumer for repair		adding 10% to the depreciation
	When repair is impossible because repair parts are not in stock within the parts retention period		amount
	Damages incurred during the transportation process and product installation at the time of purchase	Product Excha	ange
Malfunctioning due to the intentional	When repair is possible	Paid repair	
negligence of the consumer	When repair is not possible because repair parts are not in stock	Exchange the product after collecting the amount corresponding to paid repair	
	Responsibility for paid services (costs paid by the custom	ner)	

		,
1.In case of failure due to natural disaster	fire, wind damage, lightning, g	as. seawater. earthquake. etc.)

2. In case of damage or malfunction due to dropping or impact
3. In case of an external cause, not a defect in the product itself
4. In case of an external causes other than defects of the product itself
5. When replacing consumable parts that are normally worn during use

Paid repair

6. If a failure occurs due to repair or modification by a person other than the Iwin A/S center

7. Issues not specified are subject to consumer dispute resolution standards

-

If you have any problems or discomfort while using the product, Please contact the customer counseling office.

070-4797-3679

For inquiries about breakdown, A/S application, please visit the website, If you use 1:1 chat counseling, you can use it more conveniently,

www.iwin2.co.kr

Headquarters and factories: No. 321 Jikji Smart Tower 76 Jikji-daero 436beon-gil, Heungdeok-gu, Cheongju-si, Chungcheongbuk-do, Republic of Korea Tel, +82-70-4797-3679 Fax, +82-43-259-3679